



PROTECTAMESH™ ROCKSHIELD HD INSTALLATION GUIDELINES

Installation of PROTECTAMESH™ ROCKSHIELD HD Installation Guidelines:

ROLLS:

1. Custom cut pads should be wrapped around the circumference of the pipe, covering all exposed areas. Ensure that all pads are of sufficient dimension to protect the entire pipe.
2. All pad overlaps shall be placed at the 6 o'clock position of the pipe, taking care to secure the PROTECTAMESH™ ROCKSHIELD HD with a polypropylene banding.
3. Place all end to end overlaps min. 50mm; all parallel pad overlaps min.150mm.
4. All pads shall be secured to the pipe by using a min. 18mm wide polypropylene banding.
5. After pads are secured to the pipe, the backfill process may take place.

PADS:

1. All rolls should be of adequate coverage to entirely cover the circumference of the pipe.
2. PROTECTAMESH™ ROCKSHIELD HD is to be placed around pipe, whereby placing overlap portion at the 6 o'clock position of the pipe.
3. Place all end to end overlaps min. 50mm ; all parallel pad overlaps min 150mm.
4. In the event that a side overlap is used place the overlaps "shingle style". This will ensure that no backfill will protrude under the PROTECTAMESH™ ROCKSHIELD HD.
5. All rolls shall be secured to pipe by using a min. 18mm wide polypropylene banding.
6. After pads are secured to the pipe, the backfill process may take place.

All the above information is given in good faith, but the figures are typical values only and should not be taken as a guarantee of performance. Manufacturing tolerances for dimensional and technical characteristics apply and are available upon request. The company reserves the right to improve the product and adjust the specification without notice.